







# CHANGING THE CARTRIDGE

TRAINER RECOMMENDED STEPS (DIFFER SLIGHTLY FROM THE USER MANUAL)

1. Tap on the 2<sup>nd</sup> to last icon (bar graph with a triangle above it)  and then tap on the checkmark to put the pump in stop mode.
2. Tap on the 3<sup>rd</sup> icon (looks like half of a reservoir with number of units below)  and then tap on the rewind button. Tap the check mark. The threaded rod is returned. Tap the check mark.
3. Self-test is performed. Tap check mark.
4. Remove the old reservoir and detach the tubing. Take off your current infusion set and dispose of it.
5. Place the new reservoir in the pump and attach the new tubing.
6. Put new infusion set on. Don't connect the tubing to your infusion set yet!
7. Tap on the 4<sup>th</sup> icon (looks like a needle with two drips)  and then tap on the first option to fill the tubing. 
8. Enter [the correct number of units for the tubing length being used](#) and then tap the check mark. Tap the next check mark to confirm you're not connected.
9. Connect tubing back to your infusion site.
10. Tap on the 4<sup>th</sup> icon (needle with two drips) and then tap on the second option  to fill the cannula.
11. Enter [the correct number of units to fill the cannula](#), depending on the infusion set being used, then tap the check mark.
12. Put pump in run mode by tapping on the 2<sup>nd</sup> last icon (looks like bar graph with a square above it)  and then tap on the checkmark to put the pump in run mode.